

## Installing CE-200 version 1.0.0.2 with 1 or more OPTIONS on Windows XP with updates

### Installation Instructions:

Set-up your sewing machine with the embroidery unit attached.  
Connect the USB cable between the machine and your computer.  
Turn OFF the sewing machine.

- Load base software.
- Once base software is loaded, turn on the sewing machine, open software for the SINGER® FUTURA™ machine and allow FUTURA® drivers to install.
- Close FUTURA® Program.
- Turn off machine.
- Install Option programs one at a time. After loading each option program, leave the CD in the tray, turn on the sewing machine, open Futura software and enter the access code located on the back of the jewel case.
- Be sure to close the FUTURA® program and turn off the machine between installations.
- Save the update to your desktop.
- Run the update from your desktop.
- After the update is installed, turn on the sewing machine, and open software. Your program is now ready to be used.

**SINGER is sewing made easy.™**